



# PipeDesigner 3D


## SOFTWARE

### PipeDesigner 3D® Viewer Installation Instructions

#### PipeDesigner 3D Release 2019 v1

This document includes instructions for proper installation of the viewer application. Trimble recommends that you review and follow the instructions to ensure the Trimble® PipeDesigner 3D® Viewer functions properly after installation.

---

 **CAUTION** – Do not install the PipeDesigner 3D Viewer on the same computer where the PipeDesigner 3D application is located. Doing so will cause conflicts within the PipeDesigner 3D program.

---

- ▶ Preliminary Steps
- ▶ Download Procedures
- ▶ Installation Procedures
- ▶ Legal Notices

# Preliminary Steps

Perform the following procedures before beginning the installation.

## Verify Autodesk Application

Before installing this version of the PipeDesigner 3D Viewer, verify that you have a compatible Autodesk® application installed.

## Verify PipeDesigner 3D Version

**TIP** – The instructions outlined in this document pertain to the Viewer for the PipeDesigner 3D software, Release 2019 v1. Please make sure that you are installing a viewer compatible with drawings created in this version.

The Viewer is version specific and will not work with drawings created in versions other than 2019 v1. If you received the drawing from another party, please verify with the party the version of PipeDesigner 3D the drawing was created in before installing a viewer.

## Windows Applications

Make sure all Microsoft Windows® based applications on the server are closed, including e-mail software.


# Download Procedures

1. Go to our [Support Downloads website](#) or on the **Home** page, go to **Support / Login to the Portal / Downloads / 3D Viewers**.  
( <http://mepsupport.trimble.com/support/downloads/3d-viewers> )
2. From the **Find 3D Viewers for** list, select **Trimble PipeDesigner 3D** and locate the PipeDesigner 3D Viewer - Release 2019 v1.  
**TIP** – If you wish to read the product notes, select **All** to locate the correct viewer download.
3. Click **Download** to copy the file to your computer. The file is saved to your **Downloads** folder.  
**TIP** – Depending on the web browser you are currently using, you may see a download dialog, click **Save**.
4. The downloaded file is in a .zip file format. You must unzip the file before proceeding with the installation.

Continue to the Installation Procedures topic to complete the required steps.

# Installation Procedures

---

 **CAUTION** – Do not install the PipeDesigner 3D Viewer on the same computer where the PipeDesigner 3D application is located. Doing so will cause conflicts within the PipeDesigner 3D program.

---

To ensure proper behavior of the application, please follow all of the procedures as outlined in the next topics.

## Downloaded file

1. Navigate to the **Downloads** folder and unzip the file to obtain the install program.
2. Double-click on **PipeDesigner 3D Viewer 2019 v1** installation file.

**TIP** – Depending on your computer settings, you may see a .exe file extension. Also, you may receive a security warning message, which is designed to protect your computer. This message can be ignored for the Viewer installation. Click **Run**.

The **Welcome to the InstallShield Wizard for PipeDesigner 3D Viewer** screen displays.

3. Click **Next**. The **License Agreement** displays on-screen (Software End User License Agreement).
4. Read the agreement. Choose the **I accept the terms in the License Agreement** check box. Click **Next**.

**TIP** – You must accept the terms of the agreement to proceed with the installation. If desired, you can click **Print** to obtain a hard copy of the agreement.

4. In the **Complete the installation** screen, click **Install**.
5. When the installation is complete, click **Finish**.
6. Close all remaining open installation files (if applicable).

# Legal Notices

Trimble Inc.  
116 Inverness Drive East, Suite 210  
Englewood, Colorado 80112  
800-234-3758

## Copyright and Trademarks

©1999-2018, Trimble Inc. All rights reserved. Trimble, the Globe & Triangle logo and PipeDesigner 3D are trademarks of Trimble Inc., registered in the United States and in other countries. Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Other brand and product names are trademarks or registered trademarks of their respective holders.

This publication, or parts thereof, may not be reproduced in any form, by any method, for any purpose, without the written consent of Trimble Inc.

## Release Notice

This is the *Trimble PipeDesigner 3D Software Viewer Installation* (Revision A). It pertains to release 2019 v1 of the software.

The topics within this document are:

- Subject to change without written notice.
- Companies, names, and data used in any examples are fictitious.
- Screenshots included in the help topics may not be exactly as in the software application.

## Edition

Trimble PipeDesigner 3D Viewer Installation, Release 2019 v1.