

# VIEWER INSTALLATION

## **Trimble<sup>®</sup> PipeDesigner 3D<sup>®</sup> Software**

Release 2016 v1  
Revision A



## LEGAL NOTICES

### Copyright and Trademarks

©2003 - 2015 Trimble Navigation Limited. All rights reserved.

Trimble and the Globe & Triangle logo are trademarks of Trimble Navigation Limited, registered in the United States and in other countries. PipeDesigner 3D is a registered trademark of Trimble Navigation Limited. All other trademarks are the property of their respective owners.

Englewood Office  
Trimble Navigation Limited  
116 Inverness Drive East, Suite 210  
Englewood, Colorado 80112  
(800) 234-3758

### Release Notice

Trimble® PipeDesigner 3D®  
Viewer Installation, Release 2016 v1

Created Wednesday, May 13, 2015, 1:13 PM

The topics within this document are subject to change without written notice. Companies, names, and data used in any examples are fictitious.


Screenshots included in the help topics may not be exactly as in the software application.

This help file, or parts thereof, may not be reproduced in any form, by any method, for any purpose, without written consent of Trimble Navigation Limited.

# PipeDesigner 3D® Viewer Installation Instructions

## PipeDesigner 3D Release 2016 v1

**This document includes instructions for proper installation of the viewer application. Trimble recommends that you review and follow the instructions to ensure the PipeDesigner 3D® Viewer functions properly after installation.**

 **Tip** - The instructions outlined in this document pertain to the Viewer for PipeDesigner 3D software, Release 2016 v1. Please make sure that you are installing the viewer compatible with this version!


# Preliminary Steps

Perform the following procedures before beginning the installation.

## Verify Autodesk Application

Before installing this version of the PipeDesigner 3D Viewer, verify that you have a compatible Autodesk® application installed.

## Verify PipeDesigner 3D Version



 **Tip** - The instructions outlined in this document pertain to the Viewer for the PipeDesigner 3D software, Release 2016 v1. Please make sure that you are installing a viewer compatible with drawings created in this version!

The Viewer is version specific and will not work with drawings created in versions other than 2016 v1. If you received the drawing from another party, please verify with the party the version of PipeDesigner 3D the drawing was created in before installing a viewer.

## Windows Applications


Make sure all Microsoft Windows® based applications on the server are closed, including e-mail software.

## Download Procedures

1. Go to our [website](#).
2. On the *Home* page, go to **Support** and then click **Resources**.
3. Locate the PipeDesigner 3D Viewer, Release 2016 v1.  
 **Tip** - If you wish to read the product notes, click **View All Viewers** to locate the correct viewer download.
4. Click **Download** to copy the file to your computer. The file is saved to your *Downloads* folder.  
 **Tip** - Depending on the web browser you are currently using, you may see a download dialog, click **Save**.
5. The downloaded file is in a zip file format. You must unzip the file before proceeding with the installation.

Continue to the [Installation Procedures](#) topic to complete the required steps.


# Installation Procedures

 **Caution** - Do not install the PipeDesigner 3D Viewer on the same computer where the PipeDesigner 3D application is located. Doing so will cause conflicts within the PipeDesigner 3D program.

To ensure proper behavior of the application, please follow all of the procedures as outlined in the next topics.


## Downloaded File

1. Navigate to the Downloads folder and unzip the file to obtain the install program .
2. Double-click on PipeDesigner3D Viewer 2016 v1 installation file.

 **Tip** - Depending on your computer settings, you may see an *exe* file extension. Also, you may receive a security warning message, which is designed to protect your computer. This message can be ignored for the viewer installation. Click **Run**.

The *Welcome to the InstallShield Wizard for PipeDesigner 3D Viewer* screen displays. Click **Next**.

3. The *License Agreement* displays on-screen (Software End User License Agreement). Read the agreement. Choose the **I accept the terms in the License Agreement** checkbox. Click **Next**.

 **Tip** - You must accept the terms of the agreement to proceed with the installation. If desired, you can click Print to obtain a hard copy of the agreement.

4. In the *Complete the installation* screen, click **Install**.
5. When the installation is complete, click **Finish**.
6. Close all remaining open installation files (if applicable).