




PipeDesigner 3D

SOFTWARE

PipeDesigner 3D® Viewer Installation Instructions

PipeDesigner 3D Release 2018 v1

This document includes instructions for proper installation of the viewer application. Trimble recommends that you review and follow the instructions to ensure the Trimble® PipeDesigner 3D® Viewer functions properly after installation.

 **CAUTION** – Do not install the PipeDesigner 3D Viewer on the same computer where the PipeDesigner 3D application is located. Doing so will cause conflicts within the PipeDesigner 3D program.

- ▶ Preliminary Steps
- ▶ Installation Procedures
- ▶ Legal Notices

Preliminary Steps

Perform the following procedures before beginning the installation.

Verify Autodesk Application

Before installing this version of the PipeDesigner 3D Viewer, verify that you have a compatible Autodesk® application installed.

Verify PipeDesigner 3D Version

TIP – The instructions outlined in this document pertain to the Viewer for the PipeDesigner 3D software, Release 2018 v1. Please make sure that you are installing a viewer compatible with drawings created in this version.

The Viewer is version specific and will not work with drawings created in versions other than 2018 v1. If you received the drawing from another party, please verify with the party the version of PipeDesigner 3D the drawing was created in before installing a viewer.

Windows Applications

Make sure all Microsoft Windows® based applications on the server are closed, including e-mail software.

Installation Procedures

To ensure proper behavior of the application, please follow all of the procedures as outlined in the next topics.

Installation Media

1. Insert the PipeDesigner 3D Installation media into the appropriate drive of the computer.
Depending on your computer settings, the installation may not start automatically. If it does not start a few seconds after you insert the compact disk, proceed as follows:
 - a. Double-click on the Computer icon.
 - b. Locate the drive containing the PipeDesigner 3D Installation disk.
 - c. Double-click on it to display the PipeDesigner 3D installation window.
2. Click **Explore Installation Disk**. Navigate to the Installer folder and then click **PipeDesigner 3D Viewer.exe**.
TIP – Depending on your computer settings, the .exe extension may not display.
The **Welcome to the InstallShield Wizard for PipeDesigner 3D Viewer** screen displays.
3. Click **Next**. The **License Agreement** displays on-screen (Software End User License Agreement).
4. Read the agreement. Choose the **I accept the terms in the License Agreement** check box. Click **Next**.
TIP – You must accept the terms of the agreement to proceed with the installation.
If desired, you can click **Print** to obtain a hard copy of the agreement.
4. In the **Complete the installation** screen, click **Install**.
5. When the installation is complete, click **Finish**.
6. Close all remaining open installation files (if applicable).

Legal Notices

Trimble Inc.

116 Inverness Drive East, Suite 210

Englewood, Colorado 80112

800-234-3758

Copyright and Trademarks

©1999-2017, Trimble Inc. All rights reserved. Trimble, the Globe & Triangle logo and PipeDesigner 3D are trademarks of Trimble Inc., registered in the United States and in other countries. Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Other brand and product names are trademarks or registered trademarks of their respective holders.

This publication, or parts thereof, may not be reproduced in any form, by any method, for any purpose, without the written consent of Trimble Inc.

Release Notice

This is the *Trimble PipeDesigner 3D Software Viewer Installation* (Revision A). It pertains to release 2018 v1 of the software.

The topics within this document are:

- Subject to change without written notice.
- Companies, names, and data used in any examples are fictitious.
- Screenshots included in the help topics may not be exactly as in the software application.

Edition

Trimble PipeDesigner 3D Viewer Installation, Release 2018 v1.